





























































Icon List













ZVI-Z41LIT
ZVI-Z41PRO





















Application program version: [3.1.0]
Document Edition: [3.1.0]_a

www.zennio.com

Nº	Name	Icon	Nº	Name	Icon	Nº	Name	Icon
1	No Icon		2	Off 1		3	On 1	
4	Off 2		5	On 2		6	Off 3	
7	On 3		8	Light Off 1		9	Light On 1	
10	Light Off 2		11	Light On 2		12	Light On/Off	
13	Light On/Off 2		14	Enter		15	Leave	
16	Cancel		17	Accept		18	Text Off	OFF
19	Text On	ON	20	Text On/Off	ON OFF	21	Unlock	
22	Lock		23	Down		24	Up	
25	Left		26	Right		27	Arrow Down	
28	Arrow Up		29	Arrow Right		30	Arrow Left	
31	Shutter Down 1		32	Shutter Up 1		33	Shutter Down 2	
34	Shutter Up 2		35	Shutter Open (Horizontal)		36	Shutter Close (Horizontal)	
37	Shutter Left 1		38	Shutter Left 2		39	Shutter Right 2	
40	Shutter Right 1		41	Door Closed		42	Door Open	
43	Window Closed		44	Window Open		45	Minus	
46	Plus		47	Cold/Warm		48	Cooling/Heating Off	
49	Cooling/Heating On		50	Temp Decrease		51	Temp Increase	
52	AC Off		53	AC On		54	AC On/Off	
55	AC On/Off 2		56	Mode Auto		57	Mode Heat	

58	Mode Cool		59	Mode Dry		60	Mode Fan	
61	Fan High		62	Fan Auto		63	Fan Low	
64	Fan Medium		65	Fan Very High		66	Fan Very Low	
67	Fan Stop 1		68	Fan Stop 2		69	Swing Move 1	
70	Swing Move 2		71	Swing Move 3		72	Swing Stop	
73	Auto 1		74	Auto 2		75	Auto 3	
76	Scene		77	Zero		78	One	
79	Two		80	Three		81	Four	
82	Five		83	Six		84	Seven	
85	Eight		86	Nine		87	None	
88	All		89	All/None		90	Stop	
91	Stop 2		92	Play		93	Backward	
94	Forward		95	Previous		96	Next	
97	Record		98	Pause		99	Eject	
100	Volume Down		101	Volume Up		102	Sound Stop	
103	Sound Play		104	TV		105	Audio/Video	
106	Auxiliary		107	Clapperboard		108	Snapshot	
109	Clock 1		110	Clock 2		111	Clock Off 1	
112	Clock On 1		113	Clock Off 2		114	Clock On 2	
115	Timer: Cyclical		116	Timer: Once		117	Timer: Countdown	

118	Sand Clock		119	Set		120	Text OK	
121	Comfort		122	Standby		123	Economy	
124	Building Protection		125	Building Protection 2		126	Strong	
127	Very Strong		128	Warning		129	Warning: Hot	
130	Warning: Cool		131	Warning: Wind		132	Key 1	
133	Key 2		134	New		135	Setup	
136	Tool		137	Brightness Down		138	Brightness Up	
139	Contrast Down		140	Contrast Up		141	Schedule	
142	Restart		143	Themes		144	Ecologic	
145	Melody 1		146	Melody 2		147	Melody 3	
148	Forbidden		149	Zoom In		150	Zoom Out	
151	Home		152	Toilet		153	Bathroom	
154	Library		155	Kitchen		156	Bedroom	
157	Study Room		158	Living Room		159	Living Room 2	
160	Laundry Room		161	TV Room		162	Update	
163	Graphics		164	Clean		165	Trash	
166	Radiant Floor Off		167	Radiant Floor On		168	Phone: Add	
169	Phone: Info		170	Connection Error: Network		171	Connection Error: Internet	
172	Connection Error: Service		173	Connected to Remote Service		174	Phone Connected	

175	Phone Connected 2		176	Thermometer		177	Calendar	
178	Calendar Page 1		179	Calendar Page 2		180	Calendar Page 3	
181	Calendar Page 4		182	Arrow Up (Red)		183	Arrow Down (Red)	
184	Arrow Up (Green)		185	Arrow Down (Green)		186	Arrow Up (Blue)	
187	Arrow Down (Blue)		188	Arrow Up (White)		189	Arrow Down (White)	
190	Right Indicator		191	Left Indicator		192	Socket	
193	Socket (Blue)		194	Socket (Red)		195	Socket (Green)	
196	Plug		197	Information		198	Logic "And"	
199	Logic "Or"		200	Back		201	Welcome	
202	Language		203	Do Not Disturb		204	Make Up Room	
205	Service		206	Assistance		207	Emergency	
208	Presence		209	Leave 2				

Join and send us your inquiries
about Zennio devices:

<http://support.zennio.com>

Zennio Avance y Tecnología S.L.
C/ Río Jarama, 132. Nave P-8.11
45007 Toledo (Spain).

Tel. +34 925 232 002.

www.zennio.com
info@zennio.com



RoHS